

# RYO Penta

- ① Pattern length switch (3, 4 or 5 steps; can also be set by external gate/trig into RST input.)
- ② Active step indicator LED.
- ③ minishaft knob for step cv level.
- ④ minishaft knob for step cv level.
- ⑤ Active step indicator LED.
- ⑥ minishaft knob for step cv level.
- ⑦ Active step indicator LED.
- ⑧ Active step indicator LED.
- ⑨ minishaft knob for step cv level.
- ⑩ minishaft knob for step cv level.
- ⑪ Active step indicator LED.
- ⑫ Reset CV input.
- ⑬ Clock input.
- ⑭ 0 to +5V buffered output.

Width: 4hp

